

CHAPTER 15

# INSPECTION AND SERVICING

1. Periodic inspection and servicing ..... 15-1

# 1. Periodic Inspection and Servicing

Periodic inspection and servicing is necessary to keep the engine in top condition at all times.

The routine inspection period depends on engine application and usage conditions, fuel and lubricating oil quality, engine handling, etc., and cannot be definitely stated. However, a general guideline will be given here. The relationship between inspection and maintenance activities

and operating time is given below.

Refer to pertinent inspection sections of this manual for details.

1. Perform inspection at the operating times given below, and quickly correct any defects found.
2. Before reusing disassembled parts, check that they are in good condition.

## 1-1 Routine inspection

Item	Description	Operating time					
		Daily	Every 50 hours	Every 100 hours	Every 300 hours	Every 500 hours	Every 1,000 hours
Fuel system	Fuel tank level check and filling	<input type="radio"/>					
	Fuel filter cleaning		<input type="radio"/>				
	Fuel filter element replacement			<input type="radio"/>			
	Injection valve	Injection timing check				<input type="radio"/>	
	Injection pump	Injection spray inspection					<input type="radio"/>
		Main part disassembly and inspection					
Fuel feed pump	Disassembly and inspection					<input type="radio"/>	
Lubrication system	Engine side	Oil pan oil level check and replenishment	<input type="radio"/>				
		Oil change			<input type="radio"/>		
		Turn filter handle	<input type="radio"/>				
	Clutch side	Oil level check and replenishment	<input type="radio"/>				
		Oil change		<input type="radio"/> (1st time)		<input type="radio"/> (from 2nd time)	
	Lubrication (starting chain, etc.)	<input type="radio"/>					
Cooling system	Thermostat inspection				<input type="radio"/>		
	Cooling water discharge condition	<input type="radio"/>					
	Anticorrosion zinc inspection					<input type="radio"/>	
	Water pump	Water pump drive belt tension adjustment		<input type="radio"/> (1st time)		<input type="radio"/>	
Water pump disassembly and inspection						<input type="radio"/>	
Engine proper	Bolt retightening	After operation or 50 hours after restarting					
	Intake and exhaust valve head clearance adjustment				<input type="radio"/>		
	Combustion chamber cleaning					<input type="radio"/>	
	Intake and exhaust valve lapping					<input type="radio"/>	
	Piston disassembly and piston-ring inspection					<input type="radio"/>	
	Bearing and rod bolt inspection					<input type="radio"/>	
Remote control	Cable inspection and adjustment				<input type="radio"/>		
Intake and exhaust system	Intake silencer element cleaning				<input type="radio"/> (dirty condition) <input type="radio"/> (normal condition)		
	Mixing elbow interior inspection				<input type="radio"/>		
Electrical system	Alarm lamps and alarm buzzer	<input type="radio"/>					
	Battery electrolyte level check and replenishment	<input type="radio"/>					
	Alternator drive belt tension adjustment		<input type="radio"/> (1st time)		<input type="radio"/>		
	Main switch and starting button inspection				<input type="radio"/>		
Piping	Rubber pipe inspection and replacement	Should be replaced every 4 years					
Others	Flexible mount and flexible coupling	Should be replaced every 4 years					


**1-2 Routine maintenance and inspection procedures**

Only the most common maintenance items will be described here. Refer to the pertinent chapters of this manual for details on various parts and workshop service.

**1-2.1 Daily maintenance**


(1) Oil level check

Check the engine and clutch oil levels with the dipsticks, and add oil up to the top mark. Oil level must not be allowed to fall below the bottom mark.





(2) Draining the cooling water

The cooling water will freeze in cold weather, causing faulty operation and cracking of the cylinders, cylinder head, and exhaust manifold. Therefore, always drain the water from the engine after use if the engine must sit in freezing weather.



**1-2.2 Maintenance every 50 engine hours**

- (1) fuel filter  
 tank cock and remove the bowl of the fuel tank. Then clean the inside of the bowl and the fuel filter element. After reinstalling the bowl and element, open the fuel tank cock and bleed the air from the fuel system.




**CAUTION:** Change the element every 100 hours.

	Crankcase	Clutch case
Dipstick	Cylinder side cover	Top of clutch case (filling plug with dipstick)
Filler		

**CAUTION:** Use same lubricating oils for the engine and clutch.

- (2) V-belt tension adjustment (every 300 hours after 2nd adjustment)


Check the tension of the water pump drive V-belt and alternator drive V-belt, and adjust as required.



1-2.3 Maintenance every 100 engine hours

- (1) Fuel filter element replacement


Close the fuel tank cock, remove the fuel filter bowl and replace the element and clean the inside of the bowl. After reinstalling the element and bowl, open the fuel tank cock and bleed the air from the fuel system.



- (2) Oil change

While the engine is still warm, pump the lubricating oil from the crank case and clutch case with a waste oil pump and refill both cases with new oil up to the top mark on the dipstick.

If the drain plug can be used, drain the oil by removing the drain plug.



V-belt tension  
(Pushed with a force of 10 kg (22 lb) )


mm (in.)

Water pump	5 ~ 7 (0.197 ~ 0.275)
Alternator	6 ~ 10 (0.197 ~ 0.394)


- (3) Tightening bolts

Check the engine mounting bolts, cylinder head bolts, gear case bolts, and the bolts of other main parts and tighten as required.

(Refer to the bolt tightening torque table.)



Oil evacuation pump





### 1-2.4 Maintenance every 300 engine hours

#### (1) Thermostat inspection

Remove the cooling water outlet flange on the top of the cylinder body and remove and inspect the thermostat.


Cooling water outlet connection

Thermostat



#### Intake and exhaust valve adjustment


Remove the rocker arm chamber and check the intake and exhaust valve head clearance with a feeler gage. Adjust the clearance to the specified value (see the upper head clearance adjustment section for the adjustment method.)



1-2.5 Maintenance every 500 engine hours

(1) Anticorrosion zinc replacement

Replace the anticorrosion zinc at the top of cylinder head.



(2) Inspect the fuel injection system

- Injection timing check and adjustment
- Delivery valve inspection
- Nozzle inspection

• Nozzle assembly  
Refer to the FUEL SYSTEM  
for a detailed description of  
inspection methods.

(3) Inspect the rocker arm and valve