

CHAPTER 9

REDUCTION AND REVERSING GEAR

1. Construction	9-1
2. Installation	9-6
3. Handling the Reduction and Reversing Gears	9-7
4. Inspection and Servicing	9-8
5. Disassembling the Reduction and Reversing Gears	9-14
6. Reassembling the Reduction and Reversing Gears	9-17


1. Construction

1-1 Specifications


Engine model		YSM8	YSM12	
Reduction system		Two-stage reduction, spur gear		
Reversing system		Constant mesh gear		
Clutch		Wet type single-disc, mechanically operated		
Reduction ratio	Forward	1.95, 2.93	1.98, 3.06	
	Reverse	1.95, 2.93	1.98, 3.06	
Direction of rotation	Input shaft	Counter clockwise as viewed from stern		
	Output shaft	Counter clockwise as viewed from stern		
		Clockwise as viewed from stern		
Lubricating oil		SAE 20/30		
Lubricating oil capacity		0.7l (0.185 U.S. Gal.) (total)/0.2l (0.053 U.S. Gal.) (effective)		
Dry weight		21.5kg (47.3 lbs)	23.5kg (51.7 lbs)	

1-2 Construction


(1) Cross-section



(2) Drawing



1-3 Power transmission system



Forward

Model	Forward gear	Forward idle gear	Large gear	Reduction ratio
YSM8	Z = 20	Z = 35, 26	Z = 29	$35/20 \times 29/26 = 1.952$
	Z = 19	Z = 36, 22	Z = 34	$36/19 \times 34/22 = 2.928$
YSM12	Z = 24	Z = 42, 31	Z = 35	$42/24 \times 35/31 = 1.976$
		Z = 42, 24	Z = 42	$42/24 \times 42/24 = 3.063$

Reverse

Model	Reverse gear	Reverse idle gear	Forward idle gear	Large gear	Reduction ratio
YSM8	Z = 24	Z = 20—24	Z = 35—26	Z = 29	$24/24 \times 35/20 \times 29/26 = 1.952$
		Z = 19—24	Z = 36—22	Z = 34	$24/24 \times 36/19 \times 34/22 = 2.928$
YSM12	Z = 28	Z = 24—28	Z = 42—31	Z = 35	$28/28 \times 42/24 \times 35/31 = 1.976$
		Z = 24—28	Z = 42—24	Z = 42	$28/28 \times 42/24 \times 42/24 = 3.063$



1-4 Clutch transmission mechanism

The reduction and reversing gears of this engine include a forward gear, reverse gear, output shaft gear and two idle gears (a forward idle gear and a reverse idle gear). In the idle gear, the gear wheel and pinion are constructed integrally with each other.

These gears are always in mesh and rotate both forward and backward.



(1) When moving forward:

There are two friction discs. The power is transmitted to the left friction disc, then from gear B to gear C (C_0 & C_1) and gear D to drive the propeller shaft.



(2) When moving astern:


The power is transmitted to the right friction disc, and in turn to gear A, gear E (E_0 & E_1), gear C (C_0 & C_1), and gear D to drive the propeller shaft.



Thus, by operating a gear lever, the right and left friction discs are used as appropriate, depending upon the transmission mode of ahead or astern. All gears are constant meshed type, and the friction discs are normally turning in opposite directions except in their neutral position.

(3) When in neutral position:

The two friction discs are free from the friction plate, and gears A, B, C and D are all stationary even when the engine is running. A neutral positioning piece is furnished so as not to transmit power to between the friction plate and the friction discs. Therefore, "accompaniment" does not occur with the propeller shaft while the mechanism is in its neutral position.




3. Handling the Reduction and Reversing Gears

3-1 Adjustments

3-1-1 Adjusting the adjusting screw for clutch neutral position

1. Remove the cap nut on the upper inclined surface of the clutch forward shaft gear box and loosen the clamp nut.
2. Operate the engine, and with the controlling lever in the neutral position, turn the neutral position adjusting screw clockwise or counterclockwise until the output shaft coupling stops rotating (about 1/2 or 1 full).
3. After making sure the output shaft coupling will not rotate forward or backward, tighten the clamp nut.
4. After tightening the clamp nut, securely tighten the cap nut.
5. Too much tightening may break the inside spring. Be very careful.



4. Inspection and Servicing

4-1 Condition of clutch housing

- Check the clutch case for cracks using a test hammer and, if necessary, inspect by color-check. If cracks are noted, replace it with new one.
- Check each bearing housing for burning damage. If any damage is detected, measure the inside diameter. If the inside diameter has reached the wear limit, replace the housing.

4-2 Condition of each bearing

- Check each bearing for damage and rust. If a bearing is rusty or its balls, retainer, etc. are damaged, replace.
- Smooth rotation
If the rotation of a bearing is uneven or produces noise, replace it with a new one.

4-3 Condition of each gear



- Damaged tooth surface
Check the tooth surface of each gear for cracks, scratches and pitching. Replace when serious damage is found.
- Bearing of tooth surface
Check the tooth surface of each gear for bearing. If the bearing is less than 70% of the face width, find out why this has happened, and, if necessary, replace the gear. Neither the tooth top nor the tooth flank should have any bearing.
- Check the fitted part of shafts or a key grooves for cracks and burning damage and replace, when needed.
- Backlash of gear

	YSM8	YSM12
Standard value		
Forward gear and idler gear	0.12 ~ 0.2	
Reverse gear and Idler gear	(0.0047 ~ 0.0079)	
Idler gear and large gear		

Replace the gear when gear noise becomes too loud.

4-4 Friction disk

- Check the friction disk for cracks, burning damage and fracture, and repair any damage. Replace all discolored or seriously damaged friction disks.
- Check the friction disk for wear.
If its thickness is less than the values listed below, replace.



mm (in.)


	YSM8		YSM12	
	Standard value	Wear limit value	Standard value	Wear limit value
Thickness of friction disk	$6^{+0.3}_0$ (0.2362 ~ 0.2480)	4.5 (0.1772)	$6^{-0.3}_0$ (0.2362 ~ 0.2480)	4.5 (0.1772)

3. Replacing the friction disk.

- 1) Remove the clutch and take out the friction disk.
- 2) After removing the binding wire, remove the bolt.
- 3) After replacing the friction disk, tighten the bolt.
kg·m (ft·lb)

Tightening torque 2.0 to 2.5 (14.26 ~ 18.07)

- 4) By using a binding wire, bind the bolt in the direction in which the bolt is tightened.




4.5 Friction disk and neutral position holding pawl.

1. Check the friction disk and neutral position holding pawl for damage and burning damage. If they are seriously damaged, replace.
2. Friction disk wear.



	YSMB		YSM12	
	Standard dimensions	Limit dimensions	Standard dimensions	Limit dimensions
Width of friction disk	18 (0.7087)	17.8 (0.7008)	18 (0.7087)	17.8 (0.7008)

3. Neutral position holding pawl.



YSMB/YSM12	Standard dimensions	Clearance at assembly	Wear limit of component part
Outside diameter of pawl A	6 ^{-0.05} _{-0.15} (0.2303 ~ 0.2343)	0.05 ~ 0.25 (0.0020 ~ 0.0098)	0.5 (0.0197)
Diameter of hole of disk	6 ^{+0.1} ₀ (0.2362 ~ 0.2402)		
Outside diameter of pawl B	9 ^{-0.05} _{-0.15} (0.3484 ~ 0.3524)		
Diameter of hole of disk	9 ^{+0.1} ₀ (0.3543 ~ 0.3583)		

Check the pawl tip for wear.

4. Spring for neutral position holding pawl (for both YSM8 and YSM12)

Check the spring for breaks, corrosion, and permanent deformation.

mm (in.)


	Standard dimensions	Limit dimension
Free length of spring	23 mm (0.9056)	21 mm (0.8268)

4-6 Clutch housing A and clutch housing B

1. Check the friction surface of the clutch housing for cracks, damage, seizure, etc. Repair any damage. If the housing is cracked or seriously damaged, replace.

2. Wear of friction surface

After bolting clutch housing A and clutch housing B together, as shown in the diagram below, measure the wear and width of the friction surface.




mm (in.)

	YSM8		YSM12	
	Standard dimension	Wear limit dimension	Standard dimension	Wear limit dimension
Friction surface and friction surface width	33.4 mm (1.3150)	35 (1.3780)	33.4 mm (1.3150)	35 (1.3780)

4-7 V-lever and spectacle link

1. Wear of V-lever underside

Check the V-lever's surface, where it comes into contact with the roller of the hold down clamp, for damage and wear.





Note: R specifications differ from Y specifications in V-lever shape, but the two specifications are the same in shaft diameter.

2. Shaft diameter and clearance of V-lever

mm (in.)

	Standard dimensions	Clearance at assembly	Maximum allowable clearance limit
Shaft diameter A	12 ^{0.07} _{0.10} (0.4685 ~ 0.4697)	0.07 ~ 0.118 (0.0028 ~ 0.0046)	0.3 (0.0018)
Diameter of hole in lever mounting fixture	12 ^{-0.018} ₀ (0.4724 ~ 0.4731)		
Shaft diameter B	12 ^{-0.07} _{0.10} (0.4686 ~ 0.4697)	0.07 ~ 0.118 (0.0028 ~ 0.0046)	0.3 (0.0018)
Diameter of hole in clutch housing A	12 ^{-0.018} ₀ (0.4724 ~ 0.4731)		


3. Spectacle link






	Standard dimensions
Diameter of hole in V-lever	$8^{+0.020}_{-0.005}$ (0.3152 ~ 0.3157)
Diameter of pin hole in V-lever side (spectacle link)	$8^{+0.150}_{-0.115}$ (0.3195 ~ 0.3209)
Diameter of hole in friction disk side (spectacle link)	$8^{+0.015}_{-0}$ (0.3150 ~ 0.3156)
Diameter of pin	$8^{+0.015}_{-0.009}$ (0.3152 ~ 0.3156)

4-8 Hold-down clamp

YSM8-R, YSM12-R



YSM8-Y, YSM12-Y



1. Hold-down clamp Roller

Check the roller surface for damage and wear. If it is seriously damaged or worn out, replace the roller. Make sure that the roller rotates smoothly.

mm (in.)

	YSM8-R YSM12-R	YSM8-Y YSM12-Y
	Standard dimensions	Wear limit dimension
Outside diameter of roller:	15 (0.5906)	14.5 (0.5709)

2. Clearance between roller and hold-down clamp case.

mm (in.)

	Standard dimensions	Clearance at assembly	Wear limit
Shaft diameter of hold-down clamp A	18 (0.7087)	0.016 ~ 0.052 (0.0006 ~ 0.0020)	0.15 (0.0059)
Diameter of hole in hold-down clamp case A	18 (0.7087)		
Shaft diameter of hold-down clamp B	8 (0.3150)	0.013 ~ 0.043 (0.0005 ~ 0.0017)	0.15 (0.0059)
Diameter of hole in hold-down clamp case B	8 (0.3150)		

3. Spring for hold-down clamp


Check the spring for breaks, corrosion, permanent deformations, etc.

mm (in.)

	YSM8-R, YSM12-R	YSM8-Y, YSM12-Y		
	Standard dimensions	Limit dimensions	Standard dimensions	Limit dimensions
Free length of spring for hold-down clamp	19 (0.7480)	17.5 (0.6890)	31 (1.2205)	29 (1.1417)

4-9 Forward shaft and sliding shaft (for both YSM8 and YSM12)


1. Clearance between forward shaft and sliding shaft



mm (in.)



	Standard dimensions	Clearance at assembly	Maximum allowable clearance
Outside diameter of sliding shaft D1	15 ^{+0.10} _{-0.15} (0.5846 ~ 0.5866)	0.10 ~ 0.17 (0.0039 ~ 0.0067)	0.3 (0.0118)
Inside diameter of bush	15 ^{+0.02} ₀ (0.5906 ~ 0.5913)		
Outside diameter of sliding shaft D2	15 ^{+0.10} _{-0.15} (0.5846 ~ 0.5866)	0.10 ~ 0.17 (0.0039 ~ 0.0067)	0.3 (0.0118)
Inside diameter of bush	15 ^{+0.02} ₀ (0.5906 ~ 0.5913)		

4-10 Lever fork



	Standard dimension	Clearance at assembly	Clearance at limit of use	mm (in.)
Diameter of lever fork shaft	20 ⁰ _{-0.050} (0.7854 ~ 0.7874)	0.020 ~ 0.091 (0.0009 ~ 0.0036)	0.25 (0.0098)	
Diameter of hole in rear lid	20 ^{+0.041} _{+0.020} (0.7882 ~ 0.7890)			

4-11 Shifter bush and shifter driving plate



	Standard dimension	Clearance at assembly	Clearance at limit of use	mm (in.)
Width of shifter bush	16 ^{-0.032} _{0.050} (0.6280 ~ 0.6287)	0.032 ~ 0.068 (0.0013 ~ 0.0027)	0.3 (0.0018)	
Width of groove in shifter driving plate	16 ^{+0.018} ₀ (0.6299 ~ 0.6306)			

4-12 Idle gear shaft (forward side and reverse side)

1. Check bearings for burning damage. If the damage is serious, replace the idle gear shaft.
2. Check the O ring for damage. If it is seriously damaged, replace the idle gear shaft.


4-13 Output shaft

1. Check the key groove for cracking. If it is defective, replace the output shaft.
2. Check the bearing for burning damage and wear. If it is considerably damaged or worn, replace the bearing.
3. Check the oil seal section for wear. If it is considerably worn, replace the oil seal.
4. Check the oil seal. If it is defective, replace it.


5. Disassembling the Reduction and Reversing Gears

5-1 Disassembling the clutch


1. Remove split pin, slotted nut and shifter.
3. Extract the bearing



2. By straightening the bent washer remove the lock nut.




4. Remove the clamp bolts from clutch housings A and B.




5. Remove clutch housing B.

This can be removed easily by prying open the gap between A and B.


The positioning pawl and spring can jump out. Be careful. Each 4 pieces.



9. Component parts after disassembling




6. Remove the pin of the connecting spectacle link and the V-lever, pin, fixtures, housing A, and sliding shaft.




7. Remove the forward gear, its feather key and circlip.

8. Remove the forward shaft and holding friction plate.

Pull out the ball bearing at the same time.



5-2 Disassembling the idle gear and output shaft




- 1 Remove the idle shaft (1) for the forward shaft and nut.
(2) The O ring (3) bearing (4) retaining ring (5) collar, forward gear (6) and bearing (4) should be removed in the order named.
- 2 Remove the idle shaft (1) for the reverse shaft and nut.
(2) The O ring (3), bearing (7), retaining ring (8), collar, reverse gear (9) and bearing (7) should be removed in the order named.
- 3 Extract the output shaft (10) by straightening its washer and loosening its clamp nut.
The rear lid (11), bearing (12) and output gear (13) should be removed in the order named.

6. Reassembling the Reduction and Reversing Gears

Note: Rinse the component parts and reassemble them in the correct sequence.

6-1 Reassembling the idle gear and output shaft

1. Attach the output shaft.
Be careful not to damage the oil seal.



2. Attach the idle shaft for the reverse shaft along with its component parts.
Reassemble the component parts by reversing the reassembly procedures.

kg·m (ft·lb)

Tightening torque


10 (57.8 ~ 72.0)

3. Attach the idle shaft for the forward shaft along with its component parts.
Reassemble the component parts by reversing the disassembly procedures.



6-2 Reassembling the clutch

1. Reassemble the forward shaft and the friction plate (reverse) with the holding friction plate placed in between.
2. Insert the ball bearing and fit the circlip.
The bearing No. should be visible from outside.
3. Put the sliding shaft and housing A back together, and attach them to the forward shaft.
Do not fail to attach the neutral position holding spring.
4. Attach the V-lever, pin, fixture and connecting spectacle link pin.
Arrange them so that the V-lever No. coincides with the friction plate housing No.




Chapter 9 Reduction and Reversing Gear
6. Reassembling the Reduction and Reversing Gears

5. Fit the clutch housing B into place and tighten the clamp bolt.


Align the mark on housing B with that on the V-lever.
kg·m (ft·lb)

Tightening torque 2.3 to 2.7 (16.63 ~ 19.52)



6. Assemble the feather key, forward gear, ball bearing and bent washer, and tighten the lock nut.

Place them inside the forward gear face with the longer flange.



7. Mount the shifter, slotted groove and split pin.

